USER MANUAL

HITACHI Eyelash Curler
HR-530

Thank you very much for purchasing this product.
Please read this user manual carefully and use the product properly.
This product is for household use only. Please do not use for other purposes.



< 1. Safety Precautions >

Warnings:

① Do not press the heater part against eyelids.
② Do not use the product nearby children or infants.
③ Do not use the product while in vehicles.

Cautions:

① Do not use the product nearby flammable liquid such as gasoline, benzene and thinner.
② Use the product for curling eyelashes only.
③ Do not use the product while wearing contact lens.
④ Users who have eye illnesses or conjunctivitis should not use the product.
⑤ Use the product for personal use only. Do not share the product with family members or other people.
⑥ Do not leave the product turned ON.
⑦ Do not leave the product on flammable items such as vinyl and paper while the heater part is hot.
⑧ Keep out of reach of children.
⑨ Do not use the product if it has been dropped or any damage.
⑩ Before use, check if there is no transformation of the comb and heater of the head part.
⑪ Make sure to cover the head part with the cap after use.
⑫ Use the product carefully when people are around you.
⑬ If feel uncomfortable with eyes or eyelids while or after use, stop using the product and consult with a doctor or specialist.
⑭ Failure to observe the following may cause injury or a failure due to heat generation, electrolyte leakage or bursting of the battery:
- Properly use the battery according to the indication for use.
- Make sure to turn the switch OFF after use.
- Perform periodic inspections, especially for electrolyte leakage.
- Mast remove the battery when not using the product for a long period of time.
- Remove the used battery soon after use.

⑮ Do not alter, disassemble or repair by unauthorized technician.
⑯ Do not wash or splash water on the product.

< 2. Name of parts and operation >

Cap
make sure to cover
the head part after use



Proper temperature mark
inform proper temperature
by color change

Comb
use for adjusting the flow
of eyelashes

Guard

Head part
Non-detachable

Switch
when sliding the switch
upward, it will turn ON

Battery cover



Point heater
use when curling the specific
points such as lower lashes,
inner and outer corners of eyes

Main heater
use when curling
eyelashes



attachment

Cleaning brush

< 3. How to insert battery >

Cautions:

Use alkaline battery only (LR03/AAA).

If other types of battery are used, the product may not be performed well. The heater would warm up with longer time and cause battery life to be shortened.

1.Pull out the battery cover towards the direction of the arrow and remove it.

*Caution: Do not hold the head part to remove the battery cover.



2. Insert alkaline battery (LR03/AAA) into the product properly according to the battery terminal.

*Caution: If the battery places in wrong direction, the product would not be operated.



3. Fit the cutout part of battery cover to the switch part, and make sure the battery cover closed firmly.



< 4. Before use >

1. Turn the switch ON, wait until the color of proper temperature mark changes.

*It takes a few minutes until the color changes.



Caution:

Make sure to use the product at an ambient temperature between 15 - 35 degrees. When using the product at an ambient temperature below 15 degrees, it may cause the followings.

*Less curling effect.

*Shorten the battery life.

*Longer time until the color change of the proper temperature mark.

Notice:

In case the color doesn't change over 2 minutes, check if the battery is inserted correctly. When the battery is inserted correctly, change the old battery with new one.

2. The product becomes available after the color of proper temperature mark changes from purple to pink.

It would take longer time to change the color when the capacity of battery or the ambient temperature is low.



Point:

The product becomes available after the color of proper temperature mark starts to change.

< 5. How to use >

Warning:

Do not press the heater part against eyelids.

Caution:

If feel uncomfortable with eyes or eyelids while or after use, stop using the product and consult with a doctor or specialist.

Notice:

*Make sure to use the product while checking in a mirror in order to prevent eyes from hurting.

*If the heater part touches skin and feel hot, cool it down in water.

*When mascara is put on the heater part or the comb, clean it before use.

< Curling eyelashes >



1. Stand the roots of eyelashes with main heater

Place eyelashes on the main heater and turn it 90 degrees outward. After aligning the main heater parallel to eyelid, hold the position about 3 seconds.



2. Curl the tips of eyelashes with main heater

Slide the head part to the tips of eyelashes slowly. After pressing eyelashes lightly and curling, hold the position about 3 seconds.



3. Adjust the flow of lower lashes with main heater

Apply the main heater to lower lashes vertically, slowly slide it from the roots downward, then hold the position about 3 seconds.



4. Curl up-down inner and outer corner of eyes with point heater

After applying the point heater parallel to eyelid about 3 seconds, slide it from the roots to the tips slowly.

Caution:

To prevent the comb from getting into eyes make sure to point the comb outward when curling outer corner, and point the comb inward when curling inner corner.

< After use >

Turn the switch OFF, and cover the head part with the cap.

Caution:

Make sure to cover the head part with the cap after use

Must remove the battery when not using the product for a long period of time.

< Advice for good curling >



1. When curling upper lashes, it is easier to curl by holding a mirror in a lower position than eye line. When curling lower lashes, it is easier to curl by holding a mirror in an upper position than eye line.

2. Until getting used to the product, practice without switching ON.



3. Use the main heater for center parts of up-down lashes. Meanwhile, use the point heater for inner and outer corners of eyes.



4. Easy to curl well by applying the heater part nearby to the roots of eyelashes.

Coution:

Do not press the heater part against eyelids.

< Recommended usage >

1. In order to attain the desired effect, apply mascara after curling and leave it for a while. Then apply the heater part to eyelashes.

Caution:

If feel uncomfortable with eyes or eyelids, stop using the product and consult with a doctor or specialist.

2. Remove extra mascara with comb,
and separate eyelashes

Before mascara gets dry, slide the comb from the roots to the tips of eyelashes slowly.



Coutions:

*Be careful not to get the comb into eyes.

*When combing, slide the comb slowly and carefully in order to prevent fibers of mascara or removed mascara from getting into eyes.